

SUBARU WRX KIT INSTALLATION INSTRUCTIONS

Thank you for purchasing our Subaru WRX Decal Kit. The following instructions are provided for quick and easy installation of your kit. If you require further instructions on a particular process please e-mail us at briggs@racingraphix.com.

First you will want to mix an application solution. You will need a clean spray bottle, dish washing soap (Dove or Ivory will work fine). Fill you bottle with 28 oz. of water. Add three or four drops of soap and mix by shaking.

Prepare your surface. The car should be free of dirt, dust, and grease. It is also recommended that the car should NOT have been recently waxed in the past month (30 days). Windows should be free of wax and should not have been treated with Rain-X or any other type of window water removal treatment.

The tools you will need are:

Scissors

Xacto Knife or Single Edge Razor Blade

Application Solution

Squeegee or Old Credit Card or Body Filler Applicator (Available at most car parts stores)

Measuring Tape

Clean Towel

Hair Drier set on low heat (If you want to speed up the drying process)

If this is the first time you have attempted applying self adhesive graphics, we recommend applying the Hood/Nose decal first in order to get a feel for the process.

Hood/Nose Decal



Using your scissors, cut the Hood/Nose decal from the sheet.

Find the center of the hood and the center of the decal. Mark the center of the decal with a ball point pen on the transfer tape. Follow basic installation procedure below.

Basic Installation Procedure

Spray hood liberally with application solution. Peel decal release backing from decal, making sure that decal is sticking to transfer tape. Apply decal and transfer tape to car. Application solution will allow you plenty of time to make adjustments. Once your decal is properly placed, use your squeegee to remove the remaining application solution from beneath decal and transfer tape. Allow 10-15 minutes for the decal to begin sticking to the car. Carefully peel back the transfer tape while making sure decal is sticking to the car. Use towel to dry off any remaining moisture.

Window Banner



Using your scissors, cut the window banner from the rest of the kit. Now cut the Oval Star Logos from the banner. Find the center of the windshield and the center of the SUBARU decal. Mark the center of the decal on transfer tape with a ball point pen. Repeat Basic Installation Procedure.

Install Oval Star Logos approximately 3 inches from SUBARU on either side. See illustration below for example. Follow Basic Installation Procedure.



Driver and Passenger Sides



There are four parts to this installation Part A/B/C/D. These are cut apart and installed in order.

Part A



Follow Basic Installation Procedure. Align Part B with the bottom of the door. The rounded, forward edge will be approximately one eighth of an inch from the door edge.

Fold the rear bottom point into door jam and trim with knife.

Part B



Follow Basic Installation Procedure. Work from the front of the car to the rear. Use a lot of application solution. Align the bottom of Part B with the top of Part A. Allow Part B to overlap Part A about an eighth of an inch. Your seam should be in the crease of the door. This placement will help hide the seam and will barely be visible close up.

Work towards the back and allow the decal to lay over the door handles. Carefully remove the transfer tape from the door handle areas. Squirt in some more application solution. Use your squeegee to work in the vinyl around handle. Once vinyl is worked in around handle and you are sure that vinyl will lie flat, carefully trim vinyl from around handle. Repeat this procedure on rear handle as well.

Part C



Repeat Basic Installation Procedure. Simply align SUBARU on the bottom, forward section of rear door.

Part D



Follow Basic Installation Procedure. Align Stars in oval area and above SUBARU on rear door.

Final Procedure

Cut vinyl in center between all door jams and gas door jam. Work vinyl around the inside of jam for a finished look. This is best done without the use of application solution.

Repeat Parts A/B/C/D on opposite side.

One Final Note.

Allow several days of dry time before washing vehicle. Be careful not to snag corners during washing. Any bubbles that remain after installation will disappear in time, usually 30 days. Please do not puncture bubbles! This could eventually ruin your graphic.

Every kit is unique to it's installer. The kit is cut to provide customers the flexibility for use on a variety of Subaru models.